


## PN: XH-A150 / 200239 BATTERY OPERATED 10W BLUETOOTH AMPLIFIER



### Instructions for use:

1. Install TR18650 battery first, pay attention to the positive and negative electrodes! (The battery is self-purchased)
2. Connect the two cables to the speaker. Red is the positive terminal and black is the negative terminal
3. Insert the SD card with song files in the SD card slot or the USB disk with song files in the USB interface (Bluetooth connection is also available, but the Bluetooth connection needs to be started first)
4. Turn on the switch key, it will automatically read your SD card or U disk, and start to play songs. If the SD card and U disk are installed at the same time, it will read the files of U disk by default and play them (if you want to play songs of U disk, you can press ① Playlist switch key).
5. ① key is the playlist switch key. You can select to play songs from SD card, USB flash drive, or audio of connected Bluetooth device
6. ② key is the play pause button. Press it to pause, and press it again to play
7. ③ key can be a song cutting key, can also be a volume key, a quick press is to play the previous song, a long press is to reduce the volume
8. ④ key can be a song cutting key or a volume key. A quick press is to play the next song, and a long press is to increase the volume

### How do I connect Bluetooth?

Press ① key to switch to the Bluetooth mode. You do not need to remove the USB flash drive or SD card to connect to Bluetooth

1. Enable the Bluetooth function of the mobile phone
2. Locate the device for Bluetooth connection
3. Play music and listen